

## No. 2調光器盤

機 種	MDA-308I							
DMXアドレス	49	50	51	52	53	54	55	56
相	R	S	T	R	S	T	R	S
RACK	2-1-1	2-1-2	2-1-3	2-1-4	2-1-5	2-1-6	2-1-7	2-1-8
負荷名称	UH 1	UH 2	UH 3	UH 4	UH 5	UH 6	UH 7	UH 8
MCCBサイズ	30A	30A	30A	30A	30A	30A	30A	30A
備 考								

MDA-308I							
57	58	59	60	61	62	63	64
T	R	S	T	R	S	T	R
2-2-1	2-2-2	2-2-3	2-2-4	2-2-5	2-2-6	2-2-7	2-2-8
UH 9	LH 1	LH 2	LH 3	LH 4	LH 5	LH 6	F前C 1
30A	30A	30A	30A	30A	30A	30A	30A

MDA—308I							
65	66	67	68	69	70	71	72
S	T	R	S	T	R	S	T
2-3-1	2-3-2	2-3-3	2-3-4	2-3-5	2-3-6	2-3-7	2-3-8
F前C 2	FC上 1	FC上 2	FC上 3	FC上 4	FC上 5	FC上 6	FC上 7
30A	30A	30A	30A	30A	30A	30A	30A

機 種	MDA-308I							
DMXアドレス	73	74	75	76	77	78	79	80
相	R	S	T	R	S	T	R	S
RACK	2-4-1	2-4-2	2-4-3	2-4-4	2-4-5	2-4-6	2-4-7	2-4-8
負荷名称	FC上 8	FC下 1	FC下 2	FC下 3	FC下 4	FC下 5	FC下 6	FC下 7
MCCBサイズ	30A	30A	30A	30A	30A	30A	30A	30A
備 考								

MDA-308I							
81	82	83	84	85	86	87	88
T	R	S	T	R	S	T	R
2-5-1	2-5-2	2-5-3	2-5-4	2-5-5	2-5-6	2-5-7	2-5-8
FC下 8	FC後 1	FC後 2	TL上 1	TL上 2	TL下 1	TL下 2	FS上 1
30A	30A	30A	30A	30A	30A	30A	30A

MDA-308I							
89	90	91	92	93	94	95	96
S	T	R	S	T	R	S	T
2-6-1	2-6-2	2-6-3	2-6-4	2-6-5	2-6-6	2-6-7	2-6-8
<b>FS<sub>↑</sub> 2</b>	<b>FS<sub>↑</sub> 3</b>	<b>FS<sub>↑</sub> 4</b>	<b>FS<sub>↑</sub> 5</b>	<b>FS<sub>↑</sub> 6</b>	<b>FS<sub>↓</sub> 1</b>	<b>FS<sub>↓</sub> 2</b>	<b>FS<sub>↓</sub> 3</b>
30A	30A	30A	30A	30A	30A	30A	30A

No. 3調光器盤							
機 種	MDA-308I						
DMXアドレス	97	98	99	100	101	102	103
相	R	S	T	R	S	T	R
RACK	3-1-1	3-1-2	3-1-3	3-1-4	3-1-5	3-1-6	3-1-7
負荷名称	FS下 4	FS下 5	FS下 6	CL 1	CL 2	CL 3	CL 4
MCCBサイズ	30A	30A	30A	30A	30A	30A	30A
備 考							

MDA-308I							
105	106	107	108	109	110	111	112
T	R	S	T	R	S	T	R
3-2-1	3-2-2	3-2-3	3-2-4	3-2-5	3-2-6	3-2-7	3-2-8
CL 6	CL 7	CL 8	CL 9				
30A	30A	30A	30A	30A	30A	30A	30A

MDA-604I			
113	114	115	116
S	T	R	S
3-3-1	3-3-2	3-3-3	3-3-4
客席 1	客席 2	客席 3	
60A	60A	60A	60A
作業灯	強制直 作業灯	作業灯	

調光特性発生器

F-7

ディマーインターフェイスブロック

TBK-402

作業灯制御ブロック

TBK-430